

How to prepare & patch a driveway for sealing

STEP 1: TRIM AND CLEAN SURFACE



- a. Trim grass and bushes away from driveway. Sweep entire surface, removing grass cuttings and other debris. Scrape clean all cracks using a screwdriver.



- b. Scrub gasoline and oil stains with undiluted Driveway Kleen and a wire brush. Shoot stream of water into cracks and flush clean.



- c. Wash entire driveway with Driveway Kleen. Then rinse entire driveway surface with clean water.

STEP 2: REPAIR CRACKS AND HOLES



- a. Fill cracks up to ½" wide with Crack Stopper Crack Filler.



- b. For expanding cracks or climates with wide ranges in temperature, fill cracks up to ½" wide with Crack Stopper Crack & Joint Filler or Elastomeric Crack Filler.



- c. Repair large cracks, deteriorated surfaces, and small holes up to 1" deep with Driveway Crack Patch. Apply with trowel, tapering into existing surface.



- d. For holes larger & deeper than 1", use Repave Pot Hole Patch. Use tamper to pack material tight into repair. Ready for traffic immediately. Allow to cure a minimum of thirty days prior to seal coating.